SAMSUNG

DVD Television

Chassis : C16A(REV.1)
Model: DW21G5VDX/BWT

SERVICE Manual

DVD Television Cassette Recorder



CONTENTS

1. Precautions
2. Specifications
3. Disassembly and Reassembly
4. Alignment and Adjustment (Electrical)
5. Troubleshooting
6. Exploded View and Parts List
7. Electric Parts List
8. Block Diagram
9. Schematic Diagrams

ELECTRONICS

© Samsung Electronics Co., Ltd. **JAN . 2002**
Printed in Korea
AA81-00069A